S. Kunal Keshan RA2011004010051

ECE - A

Physics: Electromagnetic
Theory, Quantum
Mechanics, Waves and
Optics- 18PYB101J

305-2021 CALIBRATION OF VOLTMETER USING

POTENTIOMETER

_ O E O E E E

AIM:

To Colibrate the given voltmeter by potentiometer (i.e. to Check the graduations of Voltmeter and to determine the Corrections, if any).

APPARATUS REQUIRED:

Potentiometer, rheostat, battery (2V) or accumolators, keys, poniel Cell, high repositive, Sensitive table galanometer, given vellmera, Connecting wires, etc.

FORMULAE:

Calibrated Voltage V'= 1.08 , 1 (volt)

Where Lo = Balancing length corresponding to emf of David (decom)

OBSERVATIONS:

Length of the cuire balancing the e.m.f of the Daniel Ceal

l = Balancing Jength For Jiffment Voltmeter reading (m)

CALCULATIONS:

lo = 5.554 m.

V'= 1.08, 2; V'-V; 1.68 = 0.1944

1. V' = 1.08 x 0.618 = 0.1318; V' - V = 0.0318

2. V= 0.1944 × 1.146 = 0.2227; V'-V= 0.0227 3. V= 0.1944 × 1.752 = 0.3405; V'-V= 0.0405

4. $V' = 0.1944 \times 2.723 = 0.4321; V' - V = 0.0321$ $V' = 0.1944 \times 2.734 = 0.5314; V' - V = 0.0314$

6. V' = 0.1944 1 3.281 = 0.6378; N'- V = 0.0378


7. 0.1944 × 3.875 = V' = 0.7533; V'-V= 0.533 8. 0.1944 × 4.398 = V' = 0.8549; V'-V= 0.0549 9. 0.1944 × 5.000 = V' = 0.9720; V'-V= 0.0720 10. 0.1944 × 5.523 = V' = 1.0736; V'-V= 0.0736

RESULT:


the given Voltmeter is alitrated and Calibration graph is drawn.

CALIBRATION OF VATMETER USING POTENTIOMETER

Citcuit Diagrams



Motel Griphs:






Table:	Table: To Calibrate the given Voltmeter				
S-No	Voltmeter Reading	Bolancing Length	Calculated Vultimeter Reading	Correction	
010	(N) Nolth	(l) m	V'= 1.08 x 2 (udt)	(u'-v)	
1-	0.1	0.618	0.138	6.0318	
2	0.2	1.146	0.2227	0-0227	
3-	0.3	(-152	0.3405	0.0405	
4-	0,4	2.223	6.4321	0.032	
5.	0.5	2.734	0.5314	0.0319	
6.	0.6	3.281	0.6318	0-9318	
1.	0.7	3 8 15	0.7533	0.0533	
8-	ع.8	4.398	0.8549	0.0549	
9.	0'9	5.000	0.9720	0.0720	
10'	1.0	5.523	1-0736	0.0736	

